



INSTALLATION INSTRUCTIONS

Thank you for purchasing a LOMAX® STANCE™ Hard Cover. Agri-Cover, Inc. proudly manufactured this cover using superior quality materials and workmanship. With proper care, your cover will provide years of service and enjoyment.

NOTICE TO INSTALLER: Even if familiar with product, read instructions prior to installation as improvements may be made without notice. Always handle cover and components with care. If you have questions or problems, have serial number ready and call customer service. When done, these instructions must be given to the consumer.

NOTICE TO CONSUMER: Before using this product, read operating, maintenance and safety sections. Save these instructions for future reference.

FOR YOUR RECORDS

DATE PURCHASED: _____

WHERE PURCHASED: _____

SERIAL NUMBER: _____

(Located on decal under rear panel)



Questions? 844-566-2987
agricover.com

PREPARATION

Unpack cover components and clean truck box if dirty. Ensure air and surface temperatures are above 60° F. Typically a vehicle with a standard box is provided with two multi-piece side rails. For additional assistance, go to lomaxcovers.com for install video.

COMPONENTS

- (8) Clamps
- (2) Anchors
- (2) Driver side rails
- (2) Passenger side rails
- Pre-folded cover assembly
- Alcohol pad
- Primer

TOOLS NEEDED

- 1/2" Wrench
- Ft-lb torque wrench with 1/2" socket
- Marking tool
- Protective eyewear
- Gloves
- 7/16" Wrench
- Spring clamp - optional

NOTE: Under the rail drop-in bed liner requires minimal modification at front corner of box and back by tailgate. Over the rail drop-in bed liner requires considerable modification.

NOTE: For additional protection against the elements, locate and seal miscellaneous factory holes, crevices, stake pockets, etc. that may be in box (sealant not included).


⚠ CAUTION: Over torquing hardware may damage components.

⚠ CAUTION: Before using primer, read and understand all directions, warnings and precautions. For more information, visit [primer manufacturer's website](http://primermanufacturer.com).

⚠ DANGER: Highly flammable liquid and vapor. Do not use or store primer near fire or flame. Use in well ventilated area. No smoking. Avoid contact with eyes. Do not breathe vapor. Keep out of reach of children. Wear protective gloves and eye/face protection. May be fatal if swallowed and enters airways. May cause an allergic skin reaction. May cause drowsiness or dizziness.

NOTE: Use dry lubricant spray on latches when needed.


PARTS DIAGRAM



1: INSTALLING SIDE RAILS


NOTE: Some installs require special instructions. If required, follow special instructions for side rail attachment along with these standard instructions.

- A. Locate (2) side rail sections with matching profiles displayed in image below.
- B. On side rail section without pre-installed bracket, remove 1/4" x 3/4" carriage bolt and 1/4" nylock hex nut from rail end.
- C. Slide end of short rail (front) with mounting hole onto assembly bracket pre-installed on longer rail (rear).




- D. Attach short side rail (front) to assembly bracket with previously removed 1/4" x 3/4" carriage bolt and 1/4" nylock hex nut. Align side rails then tighten with 7/16" wrench.

NOTE: Side rails should have little to no gap at assembly bracket.



1: INSTALLING SIDE RAILS (Continued)


E. Position side rail with weather strip against inside lip of box, safety strap hole toward front of box and side rail guide set on top of box. Push side rail forward until it touches front of box.



F. At front, hold side rail with assistance of another person or a spring clamp.

G. Install first clamp as close to front of box as possible with clamp orientation that provides best grip, turn nut finger tight, then use 1/2" wrench to tighten.

IMPORTANT: To keep side rail secured on truck, ensure clamp teeth engage grooves on side rail.





NOTE: Images below illustrate clamping options. **Option A** depicts standard clamping orientation lower on the side rail. **Option B** depicts alternate clamping orientation with half of clamp assembly rotated 180° to provide better grip at top of side rail.

H. Verify side rail is level. If side rail is not level, perform one of the following:

If side rail tilts up: loosen and lower clamp, engage teeth and then retighten clamp.

If side rail tilts down: loosen and raise clamp, engage teeth and then retighten clamp.



1: INSTALLING SIDE RAILS (Continued)


I. With side rail guide set on top of box, install second clamp at side rail splice (where two side rail sections meet). Repeat clamping procedure.

NOTE: The second clamp covers the side rail splice and engages grooves on both rail sections. If clamp cannot be installed on side rail splice, install second clamp as close as possible to side rail splice favoring rail section closest to cab.

J. Install third clamp 2/3rds from front of box. Repeat clamping procedure.

K. At rear of box with side rail guide set on top of box, place rear clamp as close to tailgate as possible. Repeat clamping procedure.

IMPORTANT: Ensure clamp teeth engage grooves on side rail.



NOTE: For trucks with electric tailgates, typically side rail must be installed slightly higher to eliminate interference.

L. Repeat Step 1 to install side rail on opposite side.

M. Torque all clamps to 20 ft-lbs or value specified in special instructions (if supplied).

2: APPLYING SEAL


NOTE: For best adhesion, ensure air and surface temperatures are above 60° F.

NOTE: With a spray-in bed liner, better adhesion is possible by smoothing surface and applying an adhesion promoter.

A. Ensure bulkhead is clean, wipe top surface with alcohol pad (if needed wash and dry surface first).



IMPORTANT: Ensure tall side of seal faces cab.



B. Starting at one end, peel protective backing as you go. Align and adhere seal against front of side rail and inside edge of box to opposite corner and cut to length.

C. Firmly press adhesive along seal.


NOTE: Trim tall side of seal if necessary to ensure proper seal.



3: INSTALLING COVER

A. At front of box, carefully place header panel on side rails.

B. Hold cover's rear edge 1" above side rails and slide forward, then lower into retainment brackets.




C. With cover in horizontal position, center on side rails, then slide front tabs fully under side rails and torque to 20 ft-lbs.


D. Close cover to ensure tailgate closes properly.

IMPORTANT: Always ensure hooks and latches fully engage side rails.

NOTE: Refer to TROUBLESHOOTING section if adjustments are needed.




E. Fold cover open to horizontal position and hook bungee to storage bracket on each side.



G. Release final latch and carefully tilt cover into storage bracket grooves for vertical position, then secure safety straps to side rails.


IMPORTANT: Always ensure safety straps are attached to cover and side rails.

NOTE: Use caution if resting cover on cab during install.



3: INSTALLING COVER (Continued)


H. Swing pivot links out from clips and attach anchors.



I. With anchor's post toward cover, test placement on top of cab in flat area between ribs, then mark location. Repeat for opposite side.

IMPORTANT: Ensure 1 to 1-1/2" space between cover and closest point on cab.

NOTE: Improper placement of anchors will require ordering replacements.



J. Release pivot link from anchor and secure in clip on each side.

⚠ CAUTION: Air and surface temperatures must be above 60° F for proper adhesion.

K. Clean marked locations with alcohol pad.

L. Shake primer, squeeze at black dot to start liquid flow, then prime locations and allow to dry.

NOTE: Refer to primer manufacturers website for dry time.



⚠ CAUTION: Strong magnetic pull may cause improper placement.

M. Peel adhesive liner from anchors and adhere to marked locations. Apply pressure for 10 seconds, then close cover.

NOTE: After installation, cover should remain in closed position for at least 48 hours. During this time period, anchors bond to cab and cover typically conforms to truck box.



TROUBLESHOOTING

PROBLEM

SOLUTION

Top of tailgate hits cover when attempting to close.

Verify side rail guide is set on top of box. Side rails are not level or set too low at rear of cover, raise rails at rear of box until cover no longer interferes with tailgate operation (see Step 1).

Gap between cover and truck box or tailgate.

Verify side rail guide is set on top of box. Side rails are not level or set too high (see Step 1).

Seal on edge of cover is not sealing tight with top of side rail and truck box.

Verify side rail guide is set on top of box. Check side rails for height and level (see Step 1).

Latch doesn't engage.

Check side rails for height and level (see Step 1).
Inspect latches for jammed or broken parts.

Cover is not parallel with side rails.

With cover installed on box, loosen hardware on both retainment brackets with 7/16" wrench (DO NOT REMOVE HARDWARE). Unfold cover to closed position and square up with box. Carefully fold cover back to open position and retighten retainment brackets' hardware.

OPENING FOLDING COVER

IMPORTANT: To avoid damage or misalignment of hinge points, open cover in a smooth, fluid manner. Avoid dropping or slamming cover.

IMPORTANT: Remove debris or snow from hinges before opening cover.

HORIZONTAL POSITION

A. Open tailgate, pull release latch.



B. Fold panels toward the cab.



C. Hook bungee to storage bracket on both sides.



VERTICAL POSITION

D. From horizontal position with bungees secured, release final latch and carefully tilt cover into storage bracket grooves.



E. Secure pivot link to anchor on each side.

CLOSING FOLDING COVER

IMPORTANT: To avoid damage or misalignment of hinge points, close cover in a smooth, fluid manner. Avoid dropping or slamming cover.

IMPORTANT: Remove debris or snow from hinges before closing cover.

A. Open tailgate. If in vertical position, release pivot link and secure in clip on each side, then lower to horizontal position.


TIP: For easier removal of pivot link, push down on anchor's post with thumb.



B. Unhook bungees from storage brackets and unfold panels toward tailgate.



C. Always ensure hooks and latches fully engage side rails. Close tailgate.



ALWAYS PROPERLY SECURE COVER

⚠ WARNING: Failure to execute these steps may result in severe damage and will void your warranty.


1. Tabs engaged under side rails and properly torqued.
2. Safety straps attached to side rails.
3. Bungees hooked on storage brackets.

HORIZONTAL POSITION ONLY:

- 4^H. Latches engaged in retainment bracket.

VERTICAL POSITION ONLY:

- 4^V. Folded edge fully set in storage bracket grooves.
- 5^V. Pivot links secured to anchors without interference.



SAFETY INFORMATION

- Always ensure hooks and latches fully engage side rails.
- Ensure safety straps are attached to side rails when cover is installed.
- Ensure anchors are clear, free of interference.
- Never rest cover against cab after installation.
- Do not tow vehicle backward with cover on your truck.
- Do not cover cargo that is higher than the cover.
- Do not place object(s) on or against the cover or its framework at any time.
- Always secure cargo to ensure it does not damage cover or framework.
- Remove debris, snow or ice from cover and hinges before opening or closing cover.
- Do not use the cover's framework to tie down cargo.
- Never stand, sit or ride on the cover or allow others to do so.
- Cover does not eliminate moisture and dust from entering the truck box. Special wrappings or packaging of the cargo may be necessary.
- Due to poor ventilation, if you allow a pet/animal in the box, leave cover open. Do not allow people or animals to occupy box with the cover closed.
- Avoid excessive speeds and high winds when cover is in vertical position.
- Do not clean cover with a pressure washer.
- Keep cover completely closed or in approved horizontal or vertical position. Do not drive with only the rear panel open.
- Before entering low clearance areas, check height restrictions to ensure safe entry.
- Keep cover closed when going through automatic car washes.
- Keep hands and fingers away from all pinch points.
- Never use latch cord to lift or fold cover.
- Use caution when operating cover in windy conditions.

TIPS FOR A LONGER LASTING COVER

- Keep cover closed when not in use.
- Avoid storing cover in its horizontal or vertical position for long periods of time.
- Avoid dropping or slamming cover into closed position.
- Always remove foreign substances from cover.
- Ensure cover is properly latched while traveling and before entering automatic drive-through car washes.
- When cleaning, use mild liquid soap and water. Periodically treat cover and hinges with our COVER CARE® Cleaners and UV protectant. Never clean with petroleum or citrus based products. Petroleum based products may dry out and damage cover seal.


INSPECTION AND MAINTENANCE

The operator can perform most of inspection and maintenance. It may be necessary to review the installation and operating instructions.

- Periodically check and retighten safety strap hardware. If safety straps are damaged, replace with new hardware.
- Periodically check and retighten clamps as needed.
- Periodically check latch cords to ensure latches fully engage side rails.
- Periodically inspect cover assembly and the condition of all parts. Check for loose bolts and parts, tighten if needed. Test the operation to ensure parts are functioning properly and cover is in top operational condition.
- If latches have been damaged, replace with new ones.
- Periodically ensure anchors are clear, free of interference. If anchors have been damaged, replace with new ones.

NOTE: Inspection and maintenance should also be performed anytime a malfunction is observed or suspected. If you need assistance inspecting or servicing your cover, or if you want to order a replacement part, call the customer service number on the back page. Always use original equipment replacement parts for your cover.

Serial Number can be found under rear panel on driver side.



MANUFACTURER'S LIMITED WARRANTY

Agri-Cover, Inc. extends the following three (3) year Limited Warranty for the LOMAX® STANCE™ Hard Cover:

Agri-Cover, Inc. warrants a period of three (3) years from the date of manufacture that its LOMAX® STANCE™ Hard Cover is free from defects in workmanship under normal use for the truck model it was intended for. This Limited Warranty does not cover any damage due to accident, abuse, misuse, alteration, neglect, improper installation, or ordinary wear and tear.

Agri-Cover, Inc.'s sole obligation under this Limited Warranty is limited to the repair or replacement at its option, of defective parts only. No labor or service allowance is given or implied. IN NO EVENT SHALL AGRI-COVER, INC. BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES. AGRI-COVER, INC. EXPRESSLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES OF MERCHANTABILITY, AND THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE LIMITED WARRANTY DESCRIPTION CONTAINED HEREIN.

For warranty, have serial number ready and fill out the warranty claim form at agricover.com/warrantyclaim or call Customer Service Department at 844-566-2987 to determine if only a replacement part is needed or if the cover needs to be returned for inspection and repair. Goods to be returned must have a pre-authorized RA # (Return Authorization Number) - obtained by calling the number above. Mark the number on the package and ship it freight prepaid to address below. Agri-Cover, Inc. will pay freight to return goods to sender.

This Limited Warranty gives you specific legal rights and you may have other rights, which vary, from state to state.

For replacement parts shop at lomaxparts.com or call Customer Service at 844-566-2987.



Agri-Cover, Inc.
Customer Service Dept
3000 Hwy 281 SE
Jamestown, ND 58401
Phone: 844-566-2987

Hours: 8:00 am - 5:00 pm CST Monday through Friday, except Holidays