



- A. Place mud flaps on flat work surface (remove mud flap from vehicle if necessary) with rear side up. Place trim plate on mud flap. Ensure 1/4" of space around bottom and sides of trim plate. Use trim plate as template to mark bolt holes.
- B. Remove trim plate and drill holes with a 3/16" bit.
- C. Attach trim plate with carriage bolts and nuts. Tighten nuts with 3/8" socket. Repeat on additional mud flaps.

**TOOLS:** Protective eyewear, marking pen, drill with 3/16" bit and ratchet with 3/8" socket

## TRIM PLATE INSTALLATIONS



## STAINLESS STEEL TRIM PLATES

- Adds style
- Simple installation
- Mirrored finish trim plate and stainless steel hardware



