



## JOHN DEERE AB485 PRE-DRILLED HOLES ADDENDUM

Use these instructions to install an AB485 tarp kit. Read and follow these special instructions along with the standard instructions carefully before installing or using tarp system.

**NOTICE TO INSTALLER:** Even if familiar with hardware, read special instructions prior to installation as improvements may be made without notice. Always handle components with care. If you have questions or problems, call customer service. When done, these special instructions must be given to the consumer.

**NOTICE TO CONSUMER:** Before using this product, read safety and maintenance sections of these special instructions. Save these special instructions for future reference.



Questions? 800-233-4655  
agricover.com

# NOTICE

Be aware, several components for a John Deere AB485 install using pre-drilled holes. These components do not require drilling to install.

**NOTE:** Most holes will have pre-installed hardware which must be removed prior to install. Hardware may be used for install.

Before drilling, verify if components will install to pre-drilled holes.

The following display examples of components installed to pre-drilled holes on a John Deere AB485.

A. Cable ratchet located on front and rear of drivers side on side of box.



B. Arm pivot located on front of box.



## NOTICE (Continued)

C. Tarp stops located on front, middle and rear of passenger side on diagonal portion of box



D. Z bracket and end caps located on front and rear of passenger side on top of box rail.



