

Tools Needed: 9/16 wrench

- 1** Select desired location to mount load divider typically in pairs on front and rear bar.
- 2** Position divider on bar as shown, insert carriage bolt and start lock nut.
- 3** Adjust each load divider to desired spacing and turn lock nuts tight.

