



TRIM PLATES



Enhance your ROCKSTAR™ Splash Guard Mud Flaps with trim plates, crafted from high-quality mirrored stainless steel for a polished look. Built to resist corrosion and withstand harsh towing conditions. Each set includes stainless steel hardware for easy, secure installation. ROCKSTAR™ Trim Plates provide a simple way to add a little more style to your towing setup.

See inside for instructions.

100725 2000162_C



WARNING:

Cancer and Reproductive Harm
www.P65Warnings.ca.gov

TRIM PLATE INSTRUCTIONS

TOOLS: Protective eyewear, marking pen, drill with 3/16" bit and ratchet with 3/8" socket.

A. Place mud flaps on flat work surface (remove mud flap from vehicle if necessary) with rear side up. Place trim plate on mud flap. Ensure 1/4" of space around bottom and sides of trim plate. Use trim plate as template to mark bolt holes.

B. Remove trim plate, At marked locations, drill 3/16" holes.

C. Attach trim plate with carriage bolts and nuts, Fully tighten nuts with 3/8" socket.

D. Repeat for additional mud flaps.

