

ROLL UP TRUCK BOX COVER SPECIAL CLAMPING INSTRUCTIONS



2004-12 CHEVY COLORADO/GMC CANYON

Read and follow these special instructions along with the standard instructions carefully before installing or using this cover.

NOTICE TO INSTALLER: Even if familiar with product, read special instructions prior to installation as improvements may be made without notice. Always handle components with care. When done, these special instructions must be given to the consumer.

NOTICE TO CONSUMER: Before using this product, read special instructions. Save these special instructions for future reference.

NOTICE TO INSTALLER/CONSUMER: These instructions supersede the side rail installation step found in the standard instructions. After side rails are installed, resume standard instructions.

PREPARATION

TOOLS NEEDED

- (1) 1/2" Wrench
- (1) Protective eyewear
- (1) Spring clamp - optional

▲ CAUTION: Over torquing hardware may damage components. Do not use impact tools.

1. INSTALLING CLAMPS

IMPORTANT: Double bolt clamps in this kit function the same as standard clamps shown in the standard instructions.

A. Use standard instructions for correct height and position of side rail. Install each clamp as high as possible, with one at front and one at rear on side rail. Tighten with 1/2" wrench. Repeat Step 1 to install side rail on opposite side.

B. For remaining cover installation, refer to standard instructions.



