

HARD TRUCK BOX COVER SPECIAL CLAMP INSTRUCTIONS



2005-21 NISSAN FRONTIER

Read and follow these special instructions along with the standard instructions carefully before installing or using this cover.

NOTICE TO INSTALLER: Even if familiar with product, read special instructions prior to installation as improvements may be made without notice. Always handle components with care. When done, these special instructions must be given to the consumer.

PREPARATION

TOOLS NEEDED

- (1) 1/2" Wrench
- (1) Foot-pound torque wrench with 1/2" socket
- (1) Protective eyewear

▲ CAUTION: Over torquing hardware may damage components.

NOTE: Hardware appearance and components may vary.

1: CLAMP INSTALLATION

A. Loosen clamps and insert above Utili-Track System. Slide clamps into position along length of box. Use standard instructions for clamp locations and height and position of side rail.

B. Repeat to install clamps on opposite side.

C. Torque all clamps to 20 ft-lbs.

D. **For remaining cover installation, refer to standard instructions.**



