

MOUNTING PLATES



Easily secure traction boards, recovery gear and other corner-mounted accessories to your overland ADARAC™ Truck Bed Rack with ADATRAC™ Mounting Plates. The durable, heavy-duty construction ensures stability under load while allowing you to freely reposition items for maximum flexibility. Quick and easy to install, a versatile solution for all your off-road and overland needs.

Maximum capacity: 35 lbs. per mounting plate, do not exceed rack weight rating.

See inside for instructions.

100725 4007177_B



WARNING:

Cancer and Reproductive Harm
www.P65Warnings.ca.gov



8 34532 00737 0

MOUNTING PLATE INSTRUCTIONS

TOOLS: Protective eyewear, in-lb torque wrench with 7/16" socket, ratchet with 9/16" socket (optional), 9/16" wrench (optional) and Phillips screwdriver (optional).

▲ WARNING: Each mounting plate has a maximum load capacity of 35 lbs. DO NOT EXCEED this capacity.

SAFETY INFORMATION

- Always follow safety information in ADARAC™ and ADATRAC™ Installation Instructions (available at adarac.com).
- Only use ADATRAC™ Mounting Plates with bolt on accessories.

If ADATRAC™ is already installed preform one of the following:

Outside mount: Remove Phillips screw from end cap on one side of ADATRAC™

Inside mount: Remove nuts and bolts using ratchet with 9/16" socket and 9/16" wrench, then remove ADATRAC™.

IMPORTANT: Ensure to torque bolts to 32 ft-lbs when reinstalling ADATRAC™.

A. Insert (2) square nuts in top and bottom nut channel of ADATRAC™.

B. Place lock washers and flat washers on bolts.

C. With mounting plate in desired location, align mounting holes with nuts in top and bottom nut channels.

D. Insert bolts with lock washers and flat washers, then finger tighten to square nuts.

E. Torque bolts to 120 in-lbs (10 ft-lbs).

F. Repeat Steps A-E for remaining mounting plates.

