TRIM PLATES

ROCKSTAR™

Enhance your ROCKSTAR™ Quick Hitch Mud Flaps with trim plates available in mirrored stainless steel for a polished finish or FRP with a hexagonal patterned decal for added texture. Built for harsh towing conditions, each set includes corrosion-resistant hardware for secure installation and a stylish finishing touch.

See inside for instructions.

110626 4009988_

WARNING:
Cancer and Reproductive Harm
www.P65Warnings.ca.gov

ACI™
AGRI-COVER, INC.
OUR PRODUCTS, YOUR SOLUTIONS™

TRIM PLATE INSTRUCTIONS

TOOLS: Protective eyewear, drill with 5/16” bit and ratchet with 7/16” socket.

OPTIONAL TOOLS: Marking pen and scissors.

A. Place mud flaps on flat work surface (remove from vehicle if necessary) with rear side up.

B. Locate pin holes in mud flap, then drill 5/16” holes.

C. Insert carriage bolts or studs through trim plate and mud flap, secure with nylock serrated flange nuts, fully tighten.

D. Repeat on opposite side.

