

ROLL UP TRUCK BOX COVER SPECIAL BOLT ON SIDE RAIL INSTRUCTIONS

1988-98 CHEVY/GMC STEPSIDE BOX

Read and follow these special instructions along with the standard instructions carefully before installing or using this cover.

NOTICE TO INSTALLER: Even if familiar with product, read special instructions prior to installation as improvements may be made without notice. Always handle components with care. When done, these special instructions must be given to the consumer.

NOTICE TO CONSUMER: Before using this product, read special instructions. Save these special instructions for future reference.

PREPARATION

TOOLS NEEDED

- (1) T-40 Torx driver
- (1) Protective eyewear

▲ CAUTION: Over torquing hardware may damage components. Do not use impact tools.

1. INSTALLING SIDE RAIL

A. At front of box, remove the first, fourth and last Torx head screw from inside the box on both sides.

B. Assemble clamp by sliding a flat washer, clamp, spacer, then another washer onto supplied bolt.

C. Wind all 6 clamp assemblies halfway into the bolt holes (removed in Step 1A).

D. Insert side rail between top of clamp and box. For correct side rail height and position, refer to standard instructions.

E. Tighten clamp bolt until spacer fully contacts clamp and side of box. Use caution when tightening bolt to avoid stripping threads.

F. For remaining cover installation, refer to standard instructions.



