

ROLL UP TRUCK BOX COVER SPECIAL SIDE RAIL INSTRUCTIONS



1999-06 CHEVY/GMC STEPSIDE BOX

Read and follow these special instructions along with the standard instructions carefully before installing or using this cover.

NOTICE TO INSTALLER: Even if familiar with product, read special instructions prior to installation as improvements may be made without notice. Always handle components with care. When done, these special instructions must be given to the consumer.

NOTICE TO CONSUMER: Before using this product, read special instructions. Save these special instructions for future reference.

NOTICE TO INSTALLER/CONSUMER: These instructions supersede the side rail installation step found in the standard instructions. After side rails are installed, resume standard instructions.

PREPARATION

TOOLS NEEDED

- (1) 5/16" Hex socket
- (1) Drill
- (1) Protective eyewear

NOTE: This kit substitutes (8) #12 x 3/4" AB stitch screws in place of clamps normally used.

1. INSTALLING SIDE RAIL

A. Use standard instructions for the correct height and position of side rail prior to drilling.

B. Use a drill or screw gun with 5/16" hex socket and turn screws in. There is no need to drill a hole. Applying pressure and speed, the drill or screw gun will drive the screw through for maximum gripping power.

C. Repeat Step 1 to install side rail on opposite side.

NOTE: Side rail holes are 1/4" x 5/8" slotted vertically for adjustments.

D. For remaining cover installation, refer to standard instructions



