

# ROLL UP TRUCK BOX COVER SPECIAL SIDE RAIL CLAMPING INSTRUCTIONS

## 2001-07 CHEVY/GMC DUALY LONG BOX

Read and follow these special instructions along with the standard instructions carefully before installing or using this cover.

**NOTICE TO INSTALLER:** Even if familiar with product, read special instructions prior to installation as improvements may be made without notice. Always handle components with care. When done, these special instructions must be given to the consumer.

**NOTICE TO CONSUMER:** Before using this product, read special instructions. Save these special instructions for future reference.

**NOTICE TO INSTALLER/CONSUMER:** These instructions supersede the side rail installation step found in the standard instructions. After side rails are installed, resume standard instructions.

# PREPARATION

## TOOLS NEEDED

- Ft-lbs torque wrench with 1/2" socket
- Protective eyewear
- Spring clamp - optional

**▲ CAUTION:** Over torquing hardware may damage components.

## 1: INSTALLING SIDE RAILS

**NOTE:** Use standard instructions for clamp locations, correct height and position of side rails.

A. Ensure clamps are assembled with back half of clamp offset to upper position.

B. Starting at front of box, position clamp as high as possible and tighten.

**NOTE:** On some boxes, clamps may need to be positioned in a recessed area of box wall for sufficient clearance between wall and clamp bolt.

C. Repeat for opposite side rail.

D. Torque all clamps to 20 ft-lbs .

E. For remaining cover installation, refer to standard instructions.





