

ROLL UP TRUCK BOX COVER SPECIAL SIDE RAIL CLAMPING INSTRUCTIONS



2001-07 CHEVY/GMC DUALY LONG BOX AND 2007-ON TOYOTA TUNDRA WITHOUT DECK RAIL

Read and follow these special instructions along with the standard instructions carefully before installing or using this cover.

NOTICE TO INSTALLER: Even if familiar with product, read special instructions prior to installation as improvements may be made without notice. Always handle components with care. When done, these special instructions must be given to the consumer.

NOTICE TO CONSUMER: Before using this product, read special instructions. Save these special instructions for future reference.

NOTICE TO INSTALLER/CONSUMER: These instructions supersede the side rail installation step found in the standard instructions. After side rails are installed, resume standard instructions.

PREPARATION

TOOLS NEEDED

- (2) 1/2" Wrenches
- (1) Protective eyewear
- (1) Spring clamp - optional

▲ CAUTION: Over torquing hardware may damage components. Do not use impact tools.

1. INSTALLING COVER SIDE RAIL

- Use standard instructions for the correct height and position of side rail.
- Ensure clamps are assembled with back half of clamp offset to upper position.
- Start at front of box, position clamp as high as possible and tighten. Use standard instructions for remaining clamp locations.

NOTE: On some boxes, clamps may need to be positioned in a recessed area of box wall for sufficient clearance between wall and clamp bolt.

- Repeat for opposite side rail.
- Torque all clamps to 20 ft-lbs .
- For remaining cover installation, refer to standard instructions.



