

# ROLL UP TRUCK BOX COVER SPECIAL WEATHER SEAL INSTRUCTIONS

## 1989-04 TOYOTA TACOMA

Read and follow these special instructions along with the standard instructions carefully before installing or using this cover.

**NOTICE TO INSTALLER:** Even if familiar with product, read special instructions prior to installation as improvements may be made without notice. Always handle components with care. When done, these special instructions must be given to the consumer.

**NOTICE TO CONSUMER:** Before using this product, read special instructions. Save these special instructions for future reference.

# 1. INSTALLING SIDE RAIL

**NOTE:** For best adhesion, ensure air and surface temperatures are above 60° F.

A. After side rails are installed, clean surface at the rear corners of box. From underneath, firmly push 3-1/2" weather seal against bottom of side rail while adhering it to the box. Repeat on opposite rear corner.

**NOTE:** Side rail not shown for illustrative purpose only.

B. For remaining cover installation, refer to standard instructions.





