



12 IN.

## ACCESS® LED LIGHT INSTALLATION INSTRUCTIONS

**NOTE:** For wire connections, soldering is recommended for best performance. Avoid using crimp on or tap splice style connectors.

**NOTE:** For best adhesion, air and surface temperature should be above 60° F for at least 2 hours before adhering the LED light.

- A. Clean area where LED light will be attached with soap and water or rubbing alcohol, wipe dry.
- B. Peel protective layer from adhesive strip and adhere.
- C. Connect RED wire to a 12V positive source.
- D. Connect BLACK wire to ground.

**ACCESSLEDLIGHT.COM**

Reorder #70380



**WARNING:**

Cancer and Reproductive Harm  
[www.P65Warnings.ca.gov](http://www.P65Warnings.ca.gov)

CE FC

MADE IN CHINA  
70380\_E



8 34532 00365 5