



DIRECTIONS:

*For best adhesion, air and surface temperature should be above 60° F/ 15°C.
For wire connections, soldering is recommended for best performance. Avoid using crimp on or tap splice style connectors.*

1. Clean area where LED light is to be attached with soap and water or rubbing alcohol and wipe dry.
2. Peel protective layer from adhesive strip and attach.
3. Connect RED wire to a 12V positive source.
4. Connect BLACK wire to ground.