



CONTENTS: (2) Anchor cleats, (4) channel nuts and (4) 3/8" x 1-3/4" hex bolts

ANCHOR CLEAT INSTRUCTIONS

REQUIREMENT: ADARAC™ Rails or Cross Bars with mounting channels

TOOLS: Protective eyewear, ratchet with 9/16" socket
WARNING: Each anchor cleat has a maximum load capacity of 100 lbs. DO NOT EXCEED this capacity.

SAFETY INFORMATION

- Always distribute weight evenly
- Verify ADARAC™ and Anchor Cleats are mounted securely before loading cargo or operating truck
- Always use caution when loading or unloading cargo
- Adhere to safety warnings and cautions outlined in ADARAC™ Installation Instructions (available at adarac.com)

ANCHOR CLEAT KIT

- Quickly and easily secure cargo
- Freely reposition along cross bar
- Simple installation

ANCHOR CLEAT INSTALLATION

CROSS BAR INSTALLATION:

- A. Under cross bar, tilt (2) channel nuts into mounting channel with extended threads facing up.
- B. Align anchor cleat with channel nuts then insert bolts and tighten using ratchet with 9/16" socket.
- D. Fully tighten and secure bolts.
- E. Repeat for remaining anchor cleat.

IMPORTANT: Verify ADARAC™ Anchor Cleats are mounted securely before loading cargo or operating truck.

