

## FULL WRAP RADIUS END CAP INSTALLATION FOR WILSON TRAILER

Use these instructions to install weather seal and end caps. Read and follow these instructions along with the standard instructions carefully before installing or using tarp system.

**NOTICE TO INSTALLER:** Even if familiar with hardware, read instructions prior to installation as improvements may be made without notice. Always handle components with care. If you have questions or problems, call customer service. When done, these instructions must be given to the consumer.

**NOTICE TO CONSUMER:** Before using this product, read special instructions. Save these instructions for future reference.



Questions? 800-233-4655  
agricover.com

# PREPARATION

## COMPONENTS

- Front end cap with hardware
- Rear end cap with hardware
- "D" Weather seal
- Edge guard

## TOOLS NEEDED

- Drill with 5/16" bit
- 9/16" Socket and wrench
- T45 bit (included with kit)
- Alcohol
- Protective eyewear


## 1: ASSEMBLE FRONT END CAP

**NOTE:** Front end cap will have radius corners.

**NOTE:** For best adhesion, ensure air and surface temperatures are above 60° F.


A. Apply edge guard to inside edges of end cap and gently tap in place.

B. Clean surface with alcohol, then adhere "D" weather seal along bottom of end cap's inside edge continuous from end to end.



## 2: ATTACH END CAP TO BOX

- A. Set end cap on front of box and center.
- B. Use holes across front of end cap as template to drill (6) 5/16" holes into box.
- C. Turn (6) 3/8" x 1" self-threading hex bolts into holes at face of end cap then tighten using 9/16" wrench.



- D. Use holes in each side of end cap as template to drill (3) 5/16" holes into box.
- E. Use T45 bit (included with kit) to turn (3) 3/8" x 1" self-threading Torx head bolts into each hole.
- F. Repeat Steps 1-2 for rear end cap.

