



FULL WRAP RADIUS END CAP INSTALLATION FOR WILSON TRAILER

(front end cap shown in illustrations)


THESE INSTRUCTIONS REPLACE THE WEATHER SEAL AND END CAP STEPS IN THE OWNERS MANUAL.



- 1** a) Apply edge guard to each end of cap aligning split side of edge guard to edge of cap located as shown and gently tapping in place.
- b) Adhere "D" weather seal along inside face of cap between spacers and bottom edge of cap continuous from end to end (prep surface with clean cloth and isopropyl alcohol).



- 2** a) Set cap on front of box and center it.
- b) Across face of cap, drill $\frac{5}{16}$ " hole into box wall at each hole location.
- c) Turn a self threading hex head bolt into each hole using $\frac{9}{16}$ " wrench.



- 3** a) On each side of cap, drill $\frac{5}{16}$ " hole into box wall (3 per side).
- b) Turn a self threading Torx head bolt into each hole (3 per side). Use T45 bit with kit.

NOTE: REPEAT PROCEDURE FOR REAR END CAP. (Rear end cap will have square corners)