



End Cap with Metal Filler Installation Instructions

NOTE: Before proceeding with filler, see owners manual on typical weather seal application for end caps and finish that step first.


CAUTION: DO NOT STAND OR WALK ON END CAP OR METAL FILLER




1 On flat surface, align metal filler with end cap as shown and center it. Use prepunched holes in filler as guide and drill 5/16 hole in end cap at each hole. Apply weather seal to vertical leg of filler—to seal against end cap. At each hole, turn a 3/8 self threading screw tight. Use nut and washer on back side. Apply weather seal around edge of filler to seal at top of box.



2 Center end cap on top of box and adjust metal filler flush with end of box. Drill a 5/16 hole top down next to wind deflector as shown and fasten with 3/8 self threading screw at each end. Next, use owners manual to finish mounting end cap to box.



3 **For top mount style fillers:** Note: If box has diagonal or round corners, trim filler to match and adjust weather seal and fastening points accordingly. On top of filler, drill 5/16 holes top down (spaced evenly as shown) and fasten with 3/8 self threading screws.



4 **For side mount style fillers:** Note: If box has diagonal or round corners, trim filler to match and adjust weather seal and fastening points accordingly. At each end, drill 2 holes top down and fasten there with 3/8 self threading screws. Alongside of box, drill holes (spaced evenly as shown) and fasten with 3/8 self threading screws.