



adarak.com)

- ADARAC™ Installation Instructions (available at
- Adhere to safety warnings and cautions outlined in
- Always use caution when loading or unloading cargo
- Always use caution when loading or operating truck
- Verify ADARAC™ and Tie Downs are mounted
- Always distribute weight evenly
- Use Tie Downs to secure cargo in truck box only


SAFETY INFORMATION

▲ WARNING: Each Tie Down has a maximum load capacity of 50 lbs. DO NOT EXCEED this capacity.

TOOLS: Protective eyewear, Phillips screwdriver, ratchet and 9/16" socket

REQUIREMENT: ADARAC™ Rails with mounting channels

TIE DOWN INSTRUCTIONS




CONTENTS: (4) Tie Downs, (4) channel nuts and (4) 3/8" x 5/8" hex bolts



TIE DOWN KIT

- Quickly and easily secure cargo
- Freely reposition along rail
- Simple installation



TIE DOWN INSTALLATION

NOTE: If installing Tie Downs and ADARAC™ simultaneously proceed to Step C.

A. On both sides, use Phillips screwdriver to remove rear rack rail end cap retaining screws (#4 x 3/8") then pull rear end cap away to remove.

B. On both sides, use ratchet with 9/16" socket to remove rear upright assembly mounting bolts and keep for later. Leave channel nuts in channel.

C. Each Tie Down requires a channel nut, insert the desired quantity in each rack rail (with extended thread facing the rack rail).

NOTE: Tie Downs and uprights use the same channel nut for mounting. Typically, two channel nuts are added to each rail (to install 2 Tie Downs per rail).

D. Reinsert end cap and secure retaining screw with Phillips screwdriver.

E. Reverse Step B to reattach upright assembly to rack rails.

NOTE: For more information about installing an upright assembly, see ADARAC™ Installation Instructions (available at adarac.com).

F. Align Tie Down with channel nut then secure with a bolt. Leave loose for now.

G. Slide Tie Down assembly to desired location, then fully tighten bolt using ratchet with 9/16" socket.

H. Repeat Steps F and G for remaining Tie Downs.

I. Fully tighten and secure all Tie Down bolts.

IMPORTANT: Verify Tie Downs are mounted securely before loading cargo or operating truck.

