


# GRAIN CART HANDLE HOLDER INSTRUCTIONS



**NOTICE TO INSTALLER:** This handle holder kit is designed to be universal. Some installations will not need all parts. Before drilling holes, review both methods to determine which mounting method is most suitable.


METHOD 1: Follow instructions on pages 1 and 2 when installing kit on lower profile boxes with sufficient vertical wall surface to mount handle holder extension directly to wall without extra bracing for stability.

**Figure 1: View From Rear of Cart or Wagon**



- 1 Handle holder extension mounts to center rear of box, so it extends down as shown. Use factory punched hole at top of extension as template to drill 5/16" hole in box wall. Turn a 3/8" x 1" self tapping bolt in tight. Drill a lower hole into extension and box wall. Then turn another 3/8" self tapping bolt in tight.

**Figure 2: Pinless Handle Holder EZ-LOC® and ROLTEC® Kits**



**For EZ-LOC and ROLTEC only:**

- 2 Mount crank holder bracket to handle holder extension.

**Figure 3: Pinless Handle Holder EZ-LOC® and ROLTEC® Kits**



**For EZ-LOC and ROLTEC only:**

- 3 Mount pinless handle holder to bracket using 1/2" x 1" flange bolt with spacer.


### Figure 4: Swivel Handle Holder SRT-2® Kits



**For SRT-2 only:**

- 4 Mount swivel handle holder to handle holder extension using 3/8" x 1" bolt with nyloc nut.

METHOD 2: Follow instructions below when installing kit on high profile boxes with angled walls where the handle holder extension needs to be lowered and extra bracing is needed to stabilize it.



- 1 Mount upper holder bracket at top.
- 2 Mount holder brace to lower end of channel.
- 3 Use braces (with adjustable hole patterns) to hold handle holder extension plumb by selecting appropriate bolt pattern. When bolted to box wall, braces should hold handle holder extension plumb and secure.

**For EZ-LOC and ROLTEC only:**

- 4 Mount crank holder bracket to handle holder extension. Mount pinless handle holder to bracket using 1/2" x 1" flange bolt with spacer.

**For SRT-2 only:**

- 5 Mount swivel handle holder to bracket using 3/8" x 1" bolt with nylock nut.

