

CABLE RETURN INSTRUCTIONS

Use these instructions to install cable return. Read and follow these instructions along with the standard instructions carefully before installing or using tarp system.

NOTICE TO INSTALLER: Even if familiar with product, read instructions prior to installation as improvements may be made without notice. Always handle components with care. If you have questions or problems, call customer service. When done, these instructions must be given to the consumer.

NOTICE TO CONSUMER: Before using this product, read special instructions. Save these instructions for future reference.

PREPARATION

COMPONENTS

- Cable return assembly with hardware
- Center mounting bracket with hardware
- Cable retainer
- Retaining collar
- Vinyl cap

TOOLS NEEDED

- Drill with 5/16" bit
- 9/16" Socket and wrench
- Phillips head screwdriver
- Protective eyewear

NOTE: Hardware appearance and components may vary.

NOTE: Ensure cable runs unobstructed along entire path of travel.

STAINLESS STEEL HARDWARE

▲ CAUTION: To avoid galling of stainless steel hardware, use anti-galling spray, grease or lubricant on threads and avoid high speed when fastening. Do not use impact tools for stainless steel hardware.

A. Turn 3/8" x 1" non-stainless steel self-threading bolt in 5/16" hole to cut threads, then turn back out.

B. Turn 3/8" x 1" stainless steel bolt in for attachment. When possible, use stainless steel nuts and washers with these bolts.

1: END CAP STYLE


To mount cable return, perform one of the following:

NOTE: For stainless steel hardware, see page 2 for bolting procedures.

SQUARE END CAP


A. Unroll tarp to hang down on latch plate side and remove any existing returns.

B. Align bottom edge of cable return with top edge of box behind end cap and slide toward roll tube until mounting tab meets bottom of hem.



C. Use holes in mounting tabs as template to mark and drill 5/16" holes at each end of cable return, then secure with 3/8" x 1" bolts, lock washers and nuts.

D. Place center mounting bracket (tab up) at center of cable return. Mark and drill 5/16" hole then secure with 3/8" x 1" bolt, lock washer and nut.




RADIUS END CAP

A. Unroll tarp to hang down on latch plate side and remove any existing returns.


B. Align top edge of cable return with bottom edge of end cap and slide as close to roll tube as possible.

NOTE: Mounting tab may be bent around corner.



C. Use holes in mounting tabs as template to mark and drill 5/16" holes at each end of cable return, then secure with 3/8" x 1" bolts, lock washers and nuts.

D. Place center mounting bracket (tab down) at center of cable return. Mark and drill 5/16" hole then secure with 3/8" x 1" bolt, lock washer and nut.



2: MOUNTING LOCATION

To assemble cable return to roll tube, perform one of the following:


NOTE: "Drive side" is side of box where tarp motor or crank handle are located.

NON-DRIVE SIDE

A. Remove existing end plug and extend roll tube 4" beyond end of box.

B. Slide cable return loop, cable retainer, retaining collar and new vinyl cap onto roll tube.

C. Secure retaining collar with #14 x 1" self-drilling Phillips screw.



DRIVE SIDE

A. Remove U-joint from spline or motor to slide cable return loop, retaining collar and cable retainer over roll tube.

B. Secure retaining collar with #14 x 1" self-drilling Phillips screw then reassemble U-joint to spline or motor to roll tube.

